

A red Volkswagen Multivan T7 is shown from a side profile with its sliding door open. The interior is visible, featuring light-colored leather seats and a wooden floor. The background consists of trees and a clear sky.

Installation Guide: Flooring for Volkswagen Multivan T7

Transform the interior of your T7 with elegance and functionality. This guide will take you step-by-step through the installation of the new nautical-style flooring.

General Overview

01

Preparation

Removal of seats and cleaning of runners

02

Positioning

Insertion and alignment of the mat

03

Finishing

Re-fitting of seats and covering of runners

Follow these three simple steps to achieve a professional result. The process takes approximately 10-15 minutes, and it is advisable to work with two people to ensure precision and ease of installation.

Unpacking



Extracting the mat

Extract the mat (min 2 people), paying attention to the various parts present in the packaging.

☆ Attention

Do not use sharp or pointed tools to open the packaging; you could damage the mat and its parts!

Phase 1: Space Preparation



Seat Removal

Remove all second and third-row seats to create a clear working space. This operation is essential to ensure correct mat installation.

Cleaning Tracks

Ensure the floor tracks are completely free from debris, dust, or small objects. A clean surface guarantees optimal positioning of the covering.

Phase 2: Mat/Flooring Placement



Collaboration

Work with two people to handle the mat without creating excessive creases



Alignment

Push the mat precisely to the base of the front seats



Verification

Check for perfect alignment with the rear plastic sill

Carefully insert the mat into the vehicle. The end of the mat must be perfectly aligned with the rear plastic loading sill, with no overlaps or excessive gaps.

Phase 3: Finishing and Reassembly



Seat Installation

Reinstall the seats in the desired positions. Carefully align the seat bases with the cut-outs in the mat, corresponding to the original runners.

Ensure each seat is securely fastened and that the mat does not have creases or lifts under the bases.

Managing Exposed Runners

If you do not reinstall some seats, cover the exposed runners with appropriate caps for a clean and professional aesthetic finish.

Important Note: Cover Caps



Using Cover Caps

Use the cover caps for unused rails, ensuring an impeccable aesthetic finish.

Numbering

Check the numbering on the back of the cover caps before installation.

Assembly Order

Insert the cover caps in ascending order from left to right for a correct result.

Congratulations! You have completed the installation of your new marine flooring. Enjoy the renewed comfort and aesthetic of your Volkswagen Multivan T7.



 Instagram



Isa spa (@industria_serigrafica_affini) • Instagram profile

24 Followers, 18 Following, 13 Posts – See Instagram photos and videos from Isa spa (@industria_serigrafica_affini)

[Click here](#)